



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
01-RP10-001	RP10-001-01..Frame..
02-RP10-001	RP10-001-02..Bottom Stiffner - Right side (short)
04-RP10-001	RP10-001-04..Bottom Stiffener- Left Side (Long)
05-RP10-001	RP10-001-05..Bottom Cover (VER.2) 14-6
07-RP10-001	07-RP10-001..Bottom Cover 14-6 (rectangular)
08-RP10-001	RP10-001-08..Frame Mount Channel
09-RP10-001	RP10-001-09..Mount Bracket
10-RP10-001	RP10-001-10..Mount Bracket
11-RP10-001	RP10-001-11..Cover Strap Assembly Spacer
12-RP10-001	RP10-001-12..Front Cover Mounting Harness
12K-RP10-001	12K-RP10-001..Cover Button Kit - (2 Buttons)
13-RP10-001	RP10-001-13..Aluminum Cover
13K-RP10-001	13K-RP10-001..Aluminum Cover Kit - (22 1/2")
14-RP10-001	RP10-001-14..LH Side Chamber, Inner
15-RP10-001	15-RP10-001..LH SIDE PANEL, OUTER
18-RP10-001	18-RP10-001..Alum Cover
18K-RP10-001	18K-RP10-001..Aluminum Cover Kit (22")
21-RP10-001	RP10-001-21..Left Side - Electric Fan Upgrade Panel
22-RP10-001	RP10-001-22..Receiver-Dryer Bracket
23-RP10-001	23-RP10-001..Rear Generator Cover
24-RP10-001	24-RP10-001..Electrical box old
25-RP10-001	RP10-001-25..Electrical Box Lid
26A-RP10-001	RP10-001-26A..Compressor Bracket
27-RP10-001	RP10-001-27..Compressor Block Small
28-RP10-001	RP10-001-28..Front Mount Clamp
29-RP10-001	RP10-001-29..Right Fan Chamber (Larger Fan)
30-RP10-001	30-RP10-001..1 1/2 X90 Deg Exhaust Outlet
31-RP10-001	RP10-001-31..Generator Cover (New)
32-RP10-001	32-RP10-001..Bottom Cover Drain Hole
32a-RP10-001	32a-RP10-001..bottom drain plate
33-RP10-001	33-RP10-001.Engine Mount Plate (Front )- Serpentine Drive
34-RP10-001	34-RP10-001..Rear Motor BRKT
35-RP10-001	35-RP10-001..Bottom Plate
36-RP10-001	36-RP10-001.Electrical Box
37-RP10-001	37-RP10-001..Threaded Block
38-RP10-001	38-RP10-001.Threaded Block - compressor
40-RP10-001	40-RP10-001.Right Louver Outer Chamber
43-RP10-001	43-RP10-001..Fan Shroud ( New )
44-RP10-001	44-RP10-001..Fan Shroud Bracket#1 N/S
45-RP10-001	45-RP10-001..Fan Shroud Bracket #2 N/S Right
46-RP10-001	RP10-001-46..Condenser Spacer
47-RP10-001	RP10-001-47..Speed Sensor Bracket
48-RP10-001	48-RP10-001..RH Fan Chamber..Including Form and Weather Stripping



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
48L-RP10-001	48L-RP10-001..Right Hand Fan Panel Louverd Cover Assembly.replacement for 40A-RP101-001
49-RP10-001	49-RP10-001..Holding Bracket (N/S)
50-RP10-001	50-RP10-001..Left Hand Side Chamber
51-RP10-001	RP10-001-51..Right Louver Outer Panel
52-RP10-001	52-RP10-001..Aluminum Block
53-RP10-001	53-RP10-001..Compresor Adj Bracket
54-RP10-001	54-RP10-001..Alt. ADJ ARM 40 AMP 1 EAR
55-R10-001	RP10-001-55..Alt. Bracket
56-RP10-001	RP10-001-56..R/S - s Mount Bracket
57-RP10-001	RP10-001-57..Left Side "S" Bracket
58-RP10-001	RP10-001-58..Condenser Suppor Bracket Kit
61-RP10-001	61-RP10-001..60amp Alt. bracket/orang
63-RP10-001	63-RP10-001..Thermostat Cast Housing
64-Rp10-001	Rp10-001-64..Alum Gasket for Thermostat
65-Rp10-001	65-Rp10-001..Thermostat Gasket alum
66-RP10-001	66-RP10-001..Mount Plate - Compressor / Engine
67-RP10-001	67-RP10-001..Louver Panel
68-RP10-001	68-RP10-001..Electrical Fan Cover
69-RP10-001	RP10-001-69..Large Electrical Box Revised Facing Breaker
70-RP10-001	RP10-001-70..Large Electrical Box Lid
92-RP10-001	RP10-001-92..Capacitor Box
00-C1140	00-C1140..Filter Element Cartridge
103002	103002..Air Filter
10A0735	10A0735..Fan Belt
10a0815	10a0815..Fan Belt (104 unit)
13A0875	13A0875..Compressor Belt
PF1233	PF1233..OIL FILTERS
RP1-001	pully alignment tool
RP11-002	Vibration Mount Blue
RP11-003	Shock Pads
RP12-021	Generator ADJ Bolt
RP12-023	RP12-023..Front Sound Insulation
RP12-024	RP12-024..Side Sound Insulation
RP12-025	Chamber Plug
RP12-034	RP12-034..MH4 Hose Clamp
RP12-036	HS 10 Hose Clamp
RP12-037	RP12-037..HS 12 Hose Clamp
RP12-047	RP12-047..Compressor Bolt 5"
RP12-055	RP12-055..Weather Stripping per foot
RP12-056-K	RP12-056-K..Cover Latch Clip
RP12-056-L	RP12-056-L..Cover Latch
RP12-056	Cover Latch w/ Keeper
RP12-056K	Cover Latch Kit



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
RP12-070C	RP12-070C..Cover Oval Decal
RP12-078	RP12-078..Glow Plug for Grey Engine.
RP12-097	Generator Plug 7/8 Rubber Plug
RP12-149	RP12-149..Stainless Steel Strip
RP12-153	RP12-153..HAS 16 Hose Clamp
RP13-000	RP13-000..Boot Temp. Sensor
RP13-001	RP13-001..J2 Harness
RP13-008	RP13-008..Speed Sensor Adapter
RP13-009	Cover Sensor Adapter
RP13-010	RP13-010..60 AMP Wire Harness
RP13-000	RP13-000..Boot Temp. Sensor
RP13-001	RP13-001..J2 Harness
RP13-008	RP13-008..Speed Sensor Adapter
RP13-009	Cover Sensor Adapter
RP13-010	RP13-010..60 AMP Wire Harness
RP13-076	RP13-076..Regulator Harness
RP13-077	RP13-077..Relay Kit (For Overcharging)
RP13-078	RP13-078..Electric Fan Harness
RP13-079	Large Cooling Fan Harness
RP2-001	RP2-001..Fitting 1/4" Hose Barb
RP2-002	RP2-002..Fitting 1/4" Hose Barb 451
RP2-003	RP2-003..Fitting Fuel Check Valve
RP2-004	RP2-004..1/4 Fuel Hose / 12'
RP2-006	RP2-006..Fuel Stand Pipe
RP2-007	RP2-007..1/4" Hex Nipple
RP2-008	RP2-008..Bushing 3/8 " X 1/4"
RP2-009	RP2-009..Bushing 1/2" X 1/4"
RP2-010	RP2-010..Street Tee 3/8"
RP2-011	RP2-011..Street Tee 1/4"
RP2-012	RP2-012..1/8 Adaptor
RP2-013	RP2-013..1/8 Fitting
RP2-014	RP2-014..5/16 Straight Fitting
RP3-002	RP3-002..Air Cleaner
RP3-003	RP3-003..Air Filter Housing - (With Long Life Cartridge)
RP3-004	RP3-004 ..Air Filter Inlet Hose 1 1/2" ( 9" Length)
RP3-099	RP3-099 ..Air Filter - Restriction Gauge
RP5-000	RP5-000..Engine Tube Assembly - use with bypass thermstat
RP5-002	RP5-002..By-Pass Tube - for use with bypass thermostat
RP5-003	RP5-003..Engine Inlet Tube - use with bypass thermostat
RP5-004	RP5-004..Engine Outlet Tube
RP5-005	RP5-005..Fitting 3/8 X 45
RP5-006	RP5-006..7/8" Rad Hose (3")
RP5-006B	RP5-006B..Hose 7/8" Radiator 4" long
RP5-007	RP5-007..Fitting 5/8 Hose 90 Deg



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
RP5-008	RP5-008..Hose - Heater 5/8" (10' Length)
RP5-011	RP5-011..Fitting 5/8" Hose Straight
RP5-012	RP5-012 ..Hose - 3/8" - Deairation (12" Length)
RP5-013	RP5-013..Rad Chamber Alum. <b>30 days warranty</b>
RP5-013C	RP5-013..Rad Chamber Copper
RP5-015	RP5-015..By-Pass Adaptor
RP5-016	RP5-016..Thermostate By-Pass
RP5-018	RP5-018..5/8 Grenn Stripe 8"
RP5-020	RP5-020..Radiator Copper
Rp5-021	Rp5-021..Surge Tank (Aluminum Expansion Tank)
RP5-022	RP5-022..Top Rad Hose
RP5-023	RP5-023..Bottom Rad Hose
RP5-024	RP5-024..Top Rad Hose
RP5-026	RP5-026..Radiator Cap - 9 PSI
RP5-027	RP5-027..Bottom Rad Hose
RP5-028	RP5-028..Radiator(ver3). <b>30 days warranty</b>
RP5-028C	RP5-028C..Copper / Brass Radiator
RP5-029	RP5-029..Rad Cap 13 psi
RP5-1002	RP5-1002..Plastic Overflow Tank
RP5-1002-ALC	RP5-1002-ALC..Alum Tank Cap
RP5-1002k	RP5-1002k..plastic overflow tank
RP5-1004	RP5-1004..Overflow Tank Gasket
RP5-1005	RP5-1005..Sensor, High WT
RP5-1007	RP5-1007..Surge Tank Cap Plastic
RP5-1008	RP5-1008..Heavy Duty Alum Overflow Tank..Replacement for Rp5-1002-AL
RP5-1008-C	RP5-1008-C..Heavy Duty Alum Tank Cap
RP50-201	RP50-201..Cabin Controller
RP50-250	RP50-250..Power Module MOD 3
RP6-003	RP6-003 ..Muffler Clamp - 6"
RP6-004	RP6-004..1-1/2" Clamp
RP6-005	RP6-005..Exhaust Hangers
RP6-006	RP6-006..Muffler
RP6-008	RP6-008..Welded Flex Pipe
RP6-009	RP6-009..Muffler..Exhaust facing inside, use with old 2.5" flex pipe
RP6-010	RP6-010..45 degree exhaust elbow
RP6-081	RP6-081..Ultra Quite Muffler..exhaust facing inside, use with new 6" flex pipe
RP6-082	RP6-082..6" Flex Pipe
RP6-083	Exhaust Gasket
RP6-103	RP6-103..Exhaust Elbow
RP7-000	RP7-000..Cabin Controller - Dealer Tool (Red)
RP7-001	RP7-001..16" Red Fuse Cable
RP7-002	RP7-002..16" Red 4ga Cable
RP7-003	RP7-003..11" BLK 4ga Cable



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
RP7-004	RP7-004..10 Pin Connector
RP7-005	RP7-005..8 Connector
RP7-006	RP7-006..Alternator -Stanford..
RP7-006A	RP7-006A..Harness - Alternator (40 Amp)
RP7-007K	RP7-007K..Cover Sensor Kit
RP7-010	RP7-010..1/2" Elec Locknut
RP7-012	RP7-012..8/10 Pin Terminal
RP7-013	RP7-013..SM Connector Merret
RP7-014	RP7-014..Breaker 15a, 110 Volt
RP7-015a	RP7-015a..Med Cable Support
RP7-016	RP7-016..Breaker Boot
RP7-018	RP7-018..Strain Relief
RP7-019K	Generator Kit with Large box
RP7-019K-S	Generator Kit with small box
RP7-020	RP7-020..OIL PRESSURE SWITCH
RP7-021	RP7-021..Cover Switch
RP7-023	RP7-023..Start Capacitor For 110V Gener
RP7-024	RP7-024..Start/Glow Switch
RP7-025	RP7-025..On/Off Switch
RP7-026	RP7-026 ..Oil / Water Shut Down Light
RP7-028	RP7-028..Positive 12V. Insulated
RP7-030	RP7-030..110 Volt Single Outlet Cord
RP7-032	RP7-032..Engine Control Board
RP7-037	RP7-037..BOSCH CONTACT BASE
RP7-038	RP7-038..Battery Cable (Red) - (17' Length)
RP7-039	RP7-039..17" BLK Neg Cable
RP7-040	RP7-040..Tyco Relay
RP7-041	RP7-041..8" 6GA Cable
RP7-057	RP7-057..CFCI Receptical
RP7-059	RP7-059..Outlet Mount Plate
RP7-066	RP7-066..Harness - Regulator to Battery
RP7-067	RP7-067 ..CPU Climate Control (Core Charge Applied)
RP7-069	RP7-069..Main Engine Harness
RP7-070	RP7-070..3 Relay Single Harness
RP7-071	RP7-071..Fuse Holder with Fuse
RP7-072	RP7-072..3 Relay Single Harness (25 feet)
RP7-072-T4	RP7-072-T4..4 Relay Single Harness (25 feet)
RP7-073	RP7-073..100 AMP Fuse
RP7-074	RP7-074..Fuse-35 Amp (for Electric Fan)
RP7-083	RP7-083..Sealed Relay
RP7-085	RP7-085..Fuse Kit w/Harness
RP7-090	RP7-090..20 amp Breaker
RP7-092	RP7-092..25 A Breaker
RP7-103	RP7-103..Speed Sensor



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
RP7-214	RP7-214..Fan Temp Sensor
RP7-229	RP7-229..ELEC FAN reverse flow HS
RP7-230	RP7-230..Electrical Fan
RP7-9003	RP7-9003..Shielded Cable
RP7-9005	RP7-9005..Back Plate for RP7-9000b
RP7-901	RP7-901..Cabin Controller N/S (Ver.1 )
RP7-904	RP7-904..Ext Temp Sensor
RP8-001	RP8-001..Generator "V" Pulley
RP8-002	RP8-002..Generator Pulley Bushing
RP8-003	RP8-003..COMPRESSOR BELT
RP8-004	RP8-004..Generator Belt old
RP8-006	RP8-006..Generator Belt
RP8-007	RP8-007 ..Double Groove Pulley (Flywheel)
RP8-007A	RP8-007A..Double Groove Pulley (Flywheel)
RP8-009	RP8-009..Fan Belt
RP8-010	RP8-010..4.75 DIA Pulley
RP8-011	RP8-011..Alternator Pulley
RP8-100	RP8-100..Drive Pulley Adaptor
RP8-101	RP8-101..Drive Pulley
RP8-102	RP8-102..Generator Pulley
RP8-103	RP8-103..Idler Pulley
RP8-104	RP8-104..Idler Pulley Stand Off
RP8-104-R2	RP8-104-R2..Idler Pulley Stand Off
RP8-105	RP8-105..Idler Pulley Stand Off Washer
RP8-106	RP8-106..Tensioner
RP8-107	RP8-107..Tensioner Bracket
RP8-108	RP8-108..Serpentine Belt
RP8-110	RP8-110..Generator Pulley Ver. 2
RP8-111	RP8-111..SET SCREW FOR GEN PULLEY
RP9-002-C	RP9-002-C..Condensor ..mounting in the centre (older ver.)
RP9-002-S	RP9-002-S..Condensor..mounted all on one side
RP9-004	RP9-004..2 1/2" Clamp Rec Dry
RP9-005	RP9-005..Binary Switch A/C 1430
RP9-011	RP9-011..Condenser R134a (Ver. 2)
RP9-012	RP9-012..O-Ring #6
RP9-013	RP9-013..O-Ring # 8
RP9-014	RP9-014..O RINGS #10
RP9-015	RP9-015..4" Louver
RP9-016	RP9-016..Air Kicker
RP9-027B	RP9-027B..Rec dry w/ valve
RP9-027C	RP9-027C..Rec Dryer W/Valve & Swc
RP9-029	RP9-029..binary switch female
RP9-102	RP9-102..Blower Assembly
RP9-103	RP9-103..EVAPORATOR CORE



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
RP9-104	RP9-104..HEATER CORE (Ver. 2)
RP9-107	RP9-107..Hose Adaptor (4" Length)
RP9-108	RP9-108..Fan Switch
RP9-110	RP9-110..SOLENOID 12V
RP9-111	RP9-111..Water Valve (use with Rp9-110)
RP9-112	RP9-112..Expansion Valve
RP9-113	RP9-113..Thermostatic Switch
RP9-113K	RP9-113K..thermostatic switch with
Rp9-115	RP9-115..HVAC Box Filter
RP9-116	RP9-116..charging caps low side
RP9-117	RP9-117..Charging caps high side
RP9-120	RP9-120..Electric Coolant Control
RP9-121	RP9-121..Schrader Valve Core
RP9-132	RP9-132..Compressor Sanden Serpentine
RP9-200	RP9-200..HVAC Box
RP9-201	RP9-201..Evaporator Core
RP9-202	RP9-202..Heater Core (Version 2) (>14-6 S/N-2240)..
RP9-203	RP9-203..HVAC Box Filter
RP9-205	RP9-205..HVAC Fastening Knob
RP9-206	RP9-206..HVAC Screen
RP9-301	RP9-301..Evaporator Tube #8--#10
RP9-302	RP9-302..Evaporator Tube #8--#8
RP9-304	RP9-304..Cond. Tube Extension #6
RP9-305	RP9-305..#8 Alum Strt Tube Assy
RP9-306	RP9-306..Heat Keeper Vent
RP9-307	RP9-307..Expansion Valve Tube #8
RP9-308	RP9-308..Expansion Valve Tube #10
SSK-RP10-001	SSK-RP10-001..Stainless Steel Cover Kit(22")
SSK-RP10-003	SSK-RP10-003..Cover Kit - Stainless Steel (22 1/2")
43A-RP10-001	43A-RP10-001..fan shroud assembly
RP15-001K	RP15-001K..Fan Upgrade Kit
RP2-004 R1	RP2-004 (7004)..1/4" Fuel Hose (12ft)
RP2-005 R1	RP2-005 (70042)..5/16 Fuel hose 25 1/2" (2.25ft)
RP2-015 R1	RP2-015 (32254788)..1/8" Fuel Hose 24" (2ft)
RP2-100A	RP2-100A..Fuel Fitting Kit
RP3-001 R1	RP3-001 1 3/4" Air Cleaner Hose 2 1/8" (0.1875)
RP5-008 R1	RP5-008..28417 Heater Hose 5/8" (10ft)
RP5-018A R1	RP5-018..5/8 G/S Heater hose 6 3/4" (0.5833ft)
RP5-018B R1	RP5-018B..5/8" Green Strip Heater Hose (1.167ft)..
RP5-018C	RP5-018C..5/8 Green Stripe 8"
RP5-1001	RP5-1001..Radiator Assembly
RP5-1006K	RP5-1006K..Thermostat Extension Kit - Cast
RP5-100K	RP5-100K..Electric Fan Kit (Upgrade)
RP6-080K	RP6-080K..DX Exhaust Systems Kit



## RigMaster - Master Parts List

Use this sheet to help you look up the correct RigMaster parts

Item	Description
RP7-024K	RP7-024K..Generator box kit
RP7-069K	RP7-069K..Large Electrical box kit
RP7-103k	RP7-103k..Speed Sensor Kit
RP8-109K	RP8-109K..Generator Pulley Kit
RP9-003K	RP9-003K..Compressor (With Bushings) (Ver. 1)
RP9-006 R1	RP9-006..34-22405-6..4" Flex Duct six feet long
RP9-105	Rp9-105..Drain Hose..Discharge Tube
RP9-107 R1	*** RP9-107 (24256) ***..**3.5" Hose 3 1/2 (0.2917ft)**
RP9-128K	RP9-128K..SANDEN Compressor Kit
RP9-132K	RP9-132K..Sanden compressor, Mount plate and hardware
RP9-400	RP9-400..RP9-019-8..R134a Hose Comp. to Cond. #8 hose assembly
RP9-400K	RP9-400K..Comp to Cond AC Hose
RP9-401	RP9-401..RP9-018-10A..R134a Hose Bulk to Comp #10
RP9-401K	RP9-401K..COMPSSR-BULKHEAD
RP9-402	RP9-402..RP9-017-6A R1..R134a #6 HOSE Condenser to Receiver Dryer
RP9-403	RP9-403..RP9-017-6B..R134A Hose- Rec. Dryer to Bulkhead #6
Rp9-404	Rp9-404..RP9-018-10B..R134A hose Bulked to EV or Full lenght # 10
RP9-405	RP9-405..RP9-017-6C..R134a Hose BLKHead to EV TOR #6
RP-Box-18k	RP-Box-18k..34" X22" X12"
RP-Box-Generator	RP-Box-Generator..Generator Box
RP-Box-Muffler	RP-Box-Muffler..Muffler Box
33262	33262..Fuel Filter
GG303-0259J	GG303-0259J..Caterpillar C0.5 Diesel Engine without Alternator
GG65469J	GG65469J..Perkins T4 Engine without Alternator
GG65469J-AL	GG65469J-AL..Perkins T4 Engine with Alternator